


TIMER TO CLOSE MODULE

OPTIONAL BOARD FOR RHX®, RSX®, RMX® COMMERCIAL OPERATORS



EXPANDS THE FEATURES OF YOUR COMMERCIAL OPERATOR

Key features

- User-selectable time delay
- Timer hold input
- Auxiliary open input
- Auxiliary reversing inputs
- Automatically recognized by the operator system
- Can be selected to start when the door is opened from inputs such as the open button on the wall control, optional radio control input, or auxiliary open input via an optional device
- Installed in the operator electric box and connects to the main circuit board through an expansion port connector



INDUSTRY LEADING
COMMERCIAL & INDUSTRIAL SOLUTIONS

TIME TO CLOSE MODULE

OPTIONAL BOARD FOR RHX®, RSX®, RMX® COMMERCIAL OPERATORS

Specifications

Timer	The timer is selectable from 1 second to 5 minutes. It requires the use of one of the following monitored reversing inputs: Safe-T-Beam® photoeyes or 2-wire monitored edge
Output definitions / ratings	<p>Impending operation warning – Relay contacts to close 2 to 10 seconds prior to door closing.</p> <ul style="list-style-type: none">• 1 set of Single Pole Single Throw (SPST) normally open contacts.• Rated 3 amps at 120VAC max.
Input definitions	<p>Timer Hold –This input causes an active timer to reset and hold. The count down will restart when this input is removed. (This is a class 2 circuit)</p> <ul style="list-style-type: none">• To start a timer hold: Connect this input to ground (GND) via an optional device.• To remove a timer hold: Disconnect this input from ground (GND) via an optional device• In addition to the timer hold input, any active reversing device will reset and hold the timer.
Auxiliary open input	<p>This input causes a closed or stopped door to open, prevents an open door from closing and reverses a closing door. This input can be selected to initiate the timer. (This is a Class 2 circuit)</p> <ul style="list-style-type: none">• To start an auxiliary open: Momentarily connect this input to ground (GND) via an optional device.
Normally closed reversing input	<p>This input will reverse a closing door or prevent an open door from closing. This option is selected from a menu on the commercial operator control board.</p> <ul style="list-style-type: none">• To initiate a normally closed reverse: Momentarily disconnect this input from ground (GND) via a normally closed reversing device.
Monitored edge sensor input	<p>This input will reverse a closing door or prevent an open door from closing. Requires the use of a 2-wire Miller Edge Sensor System designed to work with the commercial operator control board. This option is selected from a menu on the control board</p> <ul style="list-style-type: none">• To initiate a monitored edge sensor reverse: Momentarily connect this input to ground (GND). <p><i>Note: This input will detect broken or short – circuited wiring to the edge sensor and will interpret these as active inputs. (No additional equipment required.)</i></p>
Power supply requirements	<p>Voltage - nominal 24V DC via the expansion port. User interface – one 12 position and one 2 position terminal block. Max Wire Size – 12 AWG, min wire size 20AWG – stranded wire.</p>



2501 S. State Hwy. 121 Bus., Suite 200, Lewisville, TX 75067
1-800-929-DOOR • sales@overhaddoor.com
overhaddoor.com